



IRON - ART

FORGED FURNITURE



ORIGINAL hand forged BEDS
10 years guarantee * Made in EU



ASSEMBLY INSTRUCTIONS

Parts of bedframe:

- 1 x headboard (A)
- 1 x footboard (A)
- 2 x sideboards (B)
- 1 x center bar (not included by single beds) (C)
- 8 x nut M8 + washers for bedsides assembly
- 8 x bolts M8x100 (for beds with wooden legs)
- 2 x bolts M8 + 2 x nut M8 and washers for center bar assembly
- 10 x plastic covers for nuts by sideboards and center bar
- 5 x plastic covers for legs

Assembly instructions:

Place the sideboards edge inside on bolts installed on the headboard. Insert washer and spring washer on the bolt and then fasten the nuts (picture 1). Do not tighten. (If you have bed with wooden legs you assemble the sideboards the same way (picture 2). Just start with putting the M8x100 bolts into openings in wooden legs.

Place the center bar to openings in the middle of the headboard so that the ends of center bar are positioned below the edge of boards (picture 3). Place the footboard in the same way as headboard. Align the bed and fasten tight all bolts, without exerting too much force. Apply plastic covers to bolts on bed legs (picture 4).

The bed does not require any special maintenance.

